

BIRD ID#:
ISSUE TITLE: IBIS-AMI Typographical Corrections
REQUESTER: Arpad Muranyi, Mentor Graphics, Inc.
DATE SUBMITTED:
DATE REVISED:
DATE ACCEPTED BY IBIS OPEN FORUM:

STATEMENT OF THE ISSUE:

Section 6c of the IBIS v5.0 specification has numerous typographical or editorial issues which may imply incorrect rules or could be confusing to the reader.

In Section 6c, "ALGORITHMIC MODELING INTERFACE (AMI)", the use of the keyword Format in parameter declarations is inconsistent with the common use of parameter tree structures. Since the Format keyword really doesn't serve a practical purpose and the existing IBIS AMI Check program does not issue an error or warning when Format is not included, the suggestion is to make the use of the keyword Format optional.

STATEMENT OF THE RESOLVED SPECIFICATIONS:

On pg. 140 replace the following lines:

```
| Usage: (required for model specific parameters)
|   In   Parameter is required Input to executable
|   Out  Parameter is Output only from executable
|   Info Information for user or EDA platform
|   InOut Required Input to executable. Executable may return different
|         value.
```

with these lines:

```
|* Usage <usage>:
|*
|* Required, where <usage> must be substituted by one of the following:
|   In   Parameter is required Input to executable
|   Out  Parameter is Output only from executable
|   Info Information for user or EDA platform
|   InOut Required Input to executable. Executable may return different
|         value.
|*
|* Note that the purpose of Usage Out or InOut is to provide a mechanism
|* for the Algorithmic Model to return a value to the EDA tool to either
|* report these values to the user, or to use these values as specified
|* by the IBIS-AMI specification if they are reserved parameters.
```

On pg. 140 replace the following lines:

```
| Type: (default is Float)
|   Float
|   Integer
|   String
|   Boolean (True/False)
|   Tap (For use by TX and RX equalizers)
|   UI (Unit Interval, 1 UI is the inverse of the data rate frequency,
|       for example 1 UI of a channel operating at 10 Gb/s is 100 ps)
```

with these lines:

```
|* Type <data_type>:
|*
|* Required, where <data_type> must be substituted by one of the following:
|   Float
|   Integer
|   String
|   Boolean (True/False)
|   Tap (For use by TX and RX equalizers)
|   UI (Unit Interval, 1 UI is the inverse of the data rate frequency,
|       for example 1 UI of a channel operating at 10 Gb/s is 100 ps)
```

On pg. 140 replace the following lines:

```
| Format: (default is range)
|   Value      <value> Single value data
|   Range      <typ value> <min value> <max value>
|   List       <typ value> <value> <value> <value> ... <value>
```

with these lines:

```
|* Format <data_format> <data>:
|*
|* Where Format is optional and <data_format> and <data> are required.
|* <data_format> and <data> must be substituted with one of the following:
|*   Value      <value> Single value data. Note that Value and Default
|*               are mutually exclusive, and must not be used together for
|*               the same parameter.
|   Range      <typ value> <min value> <max value>
|   List       <typ value> <value> <value> <value> ... <value>
```

On pg. 141 replace the following lines:

```
|           (Rx_Clock_PDF
|             (Usage Info)
|             (Type Float)
|             (Format Table
|               (Labels Row_No Time_UI Density)
|               (-50 -0.1 1e-35)
```

with these lines:

```
|           (Rx_Clock_PDF
```

```

|           (Usage Info)
|           (Type Float)
|*          (Table
|*          (Labels "Row_No" "Time_UI" "Density")
|           (-50 -0.1 1e-35)
|

```

On pg. 141 reduce the indentation of the following lines:

```

|           Gaussian <mean> <sigma>
|           Dual-Dirac <mean> <mean> <sigma>
|           Composite of two Gaussian
|           DjRj <minDj> <maxDj> <sigma>
|           Convolve Gaussian (sigma) with uniform Modulation PDF

```

On pg. 141 replace the following lines:

```

|   Default <value>:
|   Depending on the Type, <value> will provide a default value for the
|   parameter. For example, if the Type is Boolean, <value> could be True
|   or False, if the Type is Integer, the <value> can be an integer value.

```

with these lines:

```

|   Default <value>:
|*   Default and Value are mutually exclusive, and must not be used together
|*   for the same parameter. Default is not allowed for Table, Gaussian,
|*   Dual-Dirac and DjRj. Default is optional for Range, List, Corner,
|*   Increment and Steps. If a Default <value> is specified, its value must
|*   have the same Type as the parameter. For example, if Type is Boolean,
|*   <value> must be either True or False, if Type is Integer, <value> must
|*   be an integer. Also, if Default is specified, <value> must be a member
|*   of the set of allowed values of the parameter. If Default is not
|*   specified, the default value of the parameters will be the <typ> value.

```

On pg. 141 replace the following lines:

```

|   Description <string>:
|   ASCII string following Description describes a reserved parameter,
|   model specific parameter, or the Algorithmic model itself. It is used
|   by the EDA platform to convey information to the end-user. The entire
|   line has to be limited to IBIS line length specification. String
|   literals begin and end with a double quote (") and no double quotes are
|   allowed inside the string literals.

```

with these lines:

```

|   Description <string>:
|*   The string following Description may describe a reserved parameter, a
|*   model specific parameter, or the Algorithmic model itself. This string
|*   is used by the EDA platform to convey information to the end-user.
|*   Description <string> is optional, but its usage is highly recommended
|*   for describing the Algorithmic model and the model specific parameters

```

|* of the Algorithmic model. The Description string may span multiple
|* lines, but it is recommended that the text contained in the Description
|* string should not exceed 120 characters per line.

The following modifications assume that the section about Use_Init_Output starting on pg. 144 will be removed as a consequence of the corrections and simplifications made to the reference flow (BIRD 120).

On pg. 143 replace the following lines:

```
|
|         The model parameter file must be organized in the parameter
|         tree format as discussed in section 3.1.2.6 of "NOTES ON
|         ALGORITHMIC MODELING INTERFACE AND PROGRAMMING GUIDE",
|         Section 10 of this document. The file must have 2 distinct
|         sections, or sub-trees, 'Reserved_Parameters' section and
|         'Model_Specific' section with sections beginning and ending
|         with parentheses. The complete tree format is described in
|         the section 3.1.2.6 of the Section 10 of this document.
```

with these lines:

```
|
|*         The model parameter file must be organized in the parameter
|         tree format as described in section 3.1.2.6 of "NOTES ON
|         ALGORITHMIC MODELING INTERFACE AND PROGRAMMING GUIDE",
|*         Section 10 of this document. The file must contain a distinct
|*         section or sub-tree named 'Reserved_Parameters' beginning and
|*         ending with parentheses. The file may also contain another
|*         section or sub-tree named 'Model_Specific', beginning and
|*         ending with parentheses. The sub-trees 'Reserved_Parameters'
|*         and 'Model_Specific' are branches of the root of the tree.
|*
|*         All leaves of the .ami file must begin with one of the
|*         following reserved words:
|*
|*             Type
|*             Usage
|*             Description
|*             Default
|*             <data_format> or Format <data_format>
|*
|*         A branch in the .ami file is an "AMI Parameter" if it
|*         contains the leaves Type, Usage, and any of the following
|*         leaves:
|*
|*             Default
|*             <data_format> or Format <data_format>
|*
|*         and does not contain another branch. A branch which
|*         contains one or more sub-branches may only contain the
|*         (Description <string>) leaf/value pair in addition to the
|*         sub-branches.
|*
|*         The parameter string passed in and out of the DLL (described
|*         in section 3.1.2.6 of Section 10 of this document) is
|*         formatted the same way as the tree data structure in the .ami
|*         file with the following exceptions.
```

```

|*
|* The EDA tool must process the content of the .ami file so that
|* 1) the 'Reserved_Parameters' and 'Model_Specific' branch
|* names and their associated open and close parentheses "()"
|* are not included in the AMI_parameters_in string, and
|* 2) the AMI Parameter branches with Usage In or Usage InOut
|* are converted to leaf/value pairs for the AMI_parameters_in
|* string, possibly incorporating user selections. In this
|* conversion each AMI parameter branch name becomes a leaf
|* name in the AMI_parameters_in string and each leaf name
|* is followed by a white space, a value and a closing
|* parentheses ")".
|*
|* The EDA tool must include all Usage In and Usage InOut
|* AMI parameters in the AMI_parameters_in string. The AMI
|* executable model must handle gracefully anything in the
|* AMI_parameters_in string that is not a Usage In or Usage
|* InOut AMI parameter, if present.
|*
|* The AMI executable must return a string in AMI_parameters_out
|* which includes all AMI parameters of Usage InOut and Usage
|* Out. The string must be in the parameter tree format using
|* branches and leaf/value pairs. The EDA tool must handle
|* gracefully anything in the AMI_parameters_out string that
|* is not a Usage InOut or Usage Out AMI parameter, if present.
|*
|* For Usage In, the value in the "AMI Parameter" leaves are
|* determined by the EDA tool based on the "AMI Parameter"
|* branches in the .ami file. For Usage Out, the value in the
|* "AMI Parameter" leaves are determined by the Algorithmic
|* Model. For Usage InOut, the value in the "AMI Parameter"
|* leaves are first determined by the EDA tool based on the
|* "AMI Parameter" branches in the .ami file and passed into
|* the Algorithmic Model which may return a new value in the
|* "AMI Parameter" leaves after some processing.
|*

```

On pg. 144 add these lines before "Reserved Parameters:"

```

|*
|* All parameters must be in the following format:
|*
|* (parameter_name (Usage <usage>
|* (Type <data_type>
|* ({Format} <data_format> <data>)
|* (Default <value>)
|* (Description <string>))
|*
|* Notes:
|* 1) The order of the entries is not important.
|* 2) The word Format is optional as indicated by the curly
|* braces "{" and "}" and may be ignored by the EDA tools.
|* (The examples do not show the word Format).
|* 3) Certain reserved parameter names allow only certain
|* <data_format> selections, as described below.
|* 4) The <data_format> selection of Value and Default are
|* always mutually exclusive. Certain parameters may require
|* Value or Default, but Value and Default are not allowed to
|* be present together for the same parameter.
|* 5) <data_format> is always required for selections other
|* than Value.
|* 6) Default is optional for <data_format> Range, List, Corner,

```

```
|*          Increment and Steps.
|*          7) Default is not allowed for <data_format> Table, Gaussian,
|*          Dual-Dirac and DjRj.
|*
```

On pg. 144 remove the following lines:

```
|          Init>Returns_Impulse, Use_Init_Output, GetWave_Exists,
|          Max_Init_Aggressors and Ignore_Bits
```

On pg. 144 replace the following lines:

```
|          The following reserved parameters are used by the EDA tool
|          and are required if the [Algorithmic Model] keyword is
|          present. The entries following the reserved parameters
|          points to its usage, type and default value. All reserved
|          parameters must be in the following format:
|
|          (parameter_name (Usage <usage>)(Type <data_type>)
|                               (Default <values>) (Description <string>))
```

with these lines:

```
|          The following reserved parameters are used by the EDA tool
|          and are required if the [Algorithmic Model] keyword is
|*         present. The entries following the reserved parameter
|*         names determine their usage, type and value. Their value
|*         may be defined using either Default or Value but not both.
|*         Description is optional.
```

On pg. 145 remove the following lines:

```
|          The following reserved parameter provides textual description
|          to the user defined parameters.
```

On pg. 145 remove the following lines under Tx_Jitter and Tx_DCD:

```
...   If specified, they must be in the following format:
|
|          (<parameter_name> (Usage <usage>)(Type <data_type>)
|                               (Format <data format>) (Default <values>)
|                               (Description <string>))
```

On pg. 146 replace the following lines:

```
|          (Tx_Jitter (Usage Info)(Type Float)
|                               (Format Gaussian <mean> <sigma>))
|
|          (Tx_Jitter (Usage Info)(Type Float)
|                               (Format Dual-Dirac <mean> <mean> <sigma>))
```

```

|
|      (Tx_Jitter (Usage Info)(Type Float)
|                (Format DjRj <minDj> <maxDj> <sigma>))
|
|      (Tx_Jitter (Usage Info)(Type Float)
|                (Format Table
|                  (Labels Row_No Time Probability)
|                  (-5 -5e-12 1e-10)
|                  (-4 -4e-12 3e-7)
|                  (-3 -3e-12 1e-4)
|                  (-2 -2e-12 1e-2)
|                  (-1 -1e-12 0.29)
|                  (0 0 0.4)
|                  (1 1e-12 0.29)
|                  (2 2e-12 1e-2)
|                  (3 3e-12 1e-4)
|                  (4 4e-12 3e-7)
|                  (5 5e-12 1e-10) ))
|

```

with these lines:

```

|
|      (Tx_Jitter (Usage Info)(Type Float)
|*          (Gaussian <mean> <sigma>))
|
|      (Tx_Jitter (Usage Info)(Type Float)
|*          (Dual-Dirac <mean> <mean> <sigma>))
|
|      (Tx_Jitter (Usage Info)(Type Float)
|*          (DjRj <minDj> <maxDj> <sigma>))
|
|      (Tx_Jitter (Usage Info)(Type Float)
|*          (Table
|*            (Labels "Row_No" "Time" "Probability")
|              (-5 -5e-12 1e-10)
|              (-4 -4e-12 3e-7)
|              (-3 -3e-12 1e-4)
|              (-2 -2e-12 1e-2)
|              (-1 -1e-12 0.29)
|              (0 0 0.4)
|              (1 1e-12 0.29)
|              (2 2e-12 1e-2)
|              (3 3e-12 1e-4)
|              (4 4e-12 3e-7)
|              (5 5e-12 1e-10) ))
|
|*      Note: Since the rows of the Table are leaves, the first
|*      column in the Table is considered a parameter name which is
|*      a string. For this reason Type Float applies to the second
|*      and all remaining columns of each row.

```

On pg. 146 replace the following lines:

```

|
|      (Tx_DCD (Usage Info)(Type Float)
|            (Format Range <typ> <min> <max>))

```

with these lines:

```
|
|           (Tx_DCD (Usage Info)(Type Float)
|*          (Range <typ> <min> <max>))
|
```

On pg. 146 remove the following lines under Rx_Clock_PDF and Rx_Receiver_Sensitivity:

```
|           ... If specified, they must be in the
| following format:
|
|           (<parameter_name> (Usage <usage>)(Type <data_type>)
|           (Format <data format>) (Default <values>)
|           (Description <string>))
```

On pg. 147 replace the following lines:

```
|           Rx_Receiver_Sensitivity:
|
|           Rx_Receiver_Sensitivity can be of Usage Info and Out and of
|           Type Float and of Data Format Value, Range and Corner.
|           Rx_Receiver_Sensitivity tells the EDA platform the voltage
|           needed at the receiver data decision point to ensure proper
|           sampling of the equalized signal. In this example, 100 mV
|           (above +100 mV or below -100 mV) is needed to ensure the
|           signal is sampled correctly. Examples of Rx_Clock_PDF
|           declarations are:
```

with these lines:

```
|           Rx_Receiver_Sensitivity:
|
|           Rx_Receiver_Sensitivity can be of Usage Info and Out and of
|           Type Float and of Data Format Value, Range and Corner.
|           Rx_Receiver_Sensitivity tells the EDA platform the voltage
|           needed at the receiver data decision point to ensure proper
|           sampling of the equalized signal. In this example, 100 mV
|           (above +100 mV or below -100 mV) is needed to ensure the
|*          signal is sampled correctly. Examples of
|*          Rx_Receiver_Sensitivity declarations are:
```

On pg. 147 replace the following lines:

```
|           (Rx_Clock_PDF (Usage Info)(Type Float)
|           (Format Gaussian <mean> <sigma>))
|
|           (Rx_Clock_PDF (Usage Info)(Type Float)
|           (Format Dual-Dirac <mean> <mean> <sigma>))
|
|           (Rx_Clock_PDF (Usage Info)(Type Float)
|           (Format DjRj <minDj> <maxDj> <sigma>))
|
|           (Rx_Clock_PDF (Usage Info)(Type Float)
|           (Format Table
|           (Labels Row_No Time Probability)
|           (-5 -5e-12 1e-10)
|           (-4 -4e-12 3e-7))
```

```

|          (-3 -3e-12 1e-4)
|          (-2 -2e-12 1e-2)
|          (-1 -1e-12 0.29)
|          (0 0 0.4)
|          (1 1e-12 0.29)
|          (2 2e-12 1e-2)
|          (3 3e-12 1e-4)
|          (4 4e-12 3e-7)
|          (5 5e-12 1e-10) ))

```

with these lines:

```

|          (Rx_Clock_PDF (Usage Info)(Type Float)
|*          (Gaussian <mean> <sigma>))
|
|          (Rx_Clock_PDF (Usage Info)(Type Float)
|*          (Dual-Dirac <mean> <mean> <sigma>))
|
|          (Rx_Clock_PDF (Usage Info)(Type Float)
|*          (DjRj <minDj> <maxDj> <sigma>))
|
|          (Rx_Clock_PDF (Usage Info)(Type Float)
|*          (Table
|*          (Labels "Row_No" "Time" "Probability")
|          (-5 -5e-12 1e-10)
|          (-4 -4e-12 3e-7)
|          (-3 -3e-12 1e-4)
|          (-2 -2e-12 1e-2)
|          (-1 -1e-12 0.29)
|          (0 0 0.4)
|          (1 1e-12 0.29)
|          (2 2e-12 1e-2)
|          (3 3e-12 1e-4)
|          (4 4e-12 3e-7)
|          (5 5e-12 1e-10) ))
|
|*          Note: Since the rows of the Table are leaves, the first
|*          column in the Table is considered a parameter name which is
|*          a string. For this reason Type Float applies to the second
|*          and all remaining columns of each row.

```

On pg. 147 replace the following lines:

```

|          (Rx_Receiver_Sensitivity (Usage Info)(Type Float)
|          (Format Value <value>))
|
|          (Rx_Receiver_Sensitivity (Usage Info)(Type Float)
|          (Format Range <typ> <min> <max>))
|
|          (Rx_Receiver_Sensitivity (Usage Info)(Type Float)
|          (Format Corner <slow> <fast>))

```

with these lines:

```

|          (Rx_Receiver_Sensitivity (Usage Info)(Type Float)
|*          (Value <value>))

```

```

|
|           (Rx_Receiver_Sensitivity (Usage Info)(Type Float)
|*          (Range <typ> <min> <max>))
|
|           (Rx_Receiver_Sensitivity (Usage Info)(Type Float)
|*          (Corner <slow> <fast>))

```

On pg. 149 remove the following lines:

```

|           The user defined parameters must be in the following format:
|
|           (<parameter_name> (usage <usage>) (Type <data type>)
|           (Format <data format>) (Default <values>)
|           (Description <string>))
|

```

On pg. 150 replace the following lines:

```

(Model_Specific          | Required heading
  (txtaps
    (-2 (Usage Inout)(Type Tap) (Format Range 0.1 -0.1 0.2)(Default 0.1)
      (Description "Second Precursor Tap"))
    (-1 (Usage Inout)(Type Tap) (Format Range 0.2 -0.4 0.4)(Default 0.2)
      (Description "First Precursor Tap"))
    (0  (Usage Inout)(Type Tap) (Format Range 1 -1 2)(Default 1)
      (Description "Main Tap"))
    (1  (Usage Inout)(Type Tap) (Format Range 0.2 -0.4 0.4)(Default2 0.2)
      (Description "First Post cursor Tap"))
    (2  (Usage Inout)(Type Tap) (Format Range 0.1 -0.1 0.2)(Default 0.1)
      (Description "Second Post cursor Tap"))
  )
  (tx_freq_offset (Format Range 1 0 150) (Type UI) (Default 0))
)
)
)
| End txtaps
| End Model_Specific
| End SampleAMI

```

with these lines:

```

(Model_Specific          | Required heading
  (txtaps
*   (-2 (Usage Inout)(Type Tap) (Range 0.1 -0.1 0.2)(Default 0.1)
      (Description "Second Precursor Tap"))
*   (-1 (Usage Inout)(Type Tap) (Range 0.2 -0.4 0.4)(Default 0.2)
      (Description "First Precursor Tap"))
*   (0  (Usage Inout)(Type Tap) (Range 1 -1 2)(Default 1)
      (Description "Main Tap"))
*   (1  (Usage Inout)(Type Tap) (Range 0.2 -0.4 0.4)(Default2 0.2)
      (Description "First Post cursor Tap"))
*   (2  (Usage Inout)(Type Tap) (Range 0.1 -0.1 0.2)(Default 0.1)
      (Description "Second Post cursor Tap"))
  )
  (tx_freq_offset (Range 1 0 150) (Type UI) (Default 0))
)
)
)
| End txtaps
| End Model_Specific
| End SampleAMI

```

Also, make sure "data format" is spelled consistently as "Data Format" or

"data_format" or "Data_Format" or what have you...

The syntax for a leaf is:

<leaf>: (<parameter name> whitespace <value list>)

So in a Table which is written like this: (-50 -0.1 1e-35), -50 is actually a parameter name, i.e. a string, not a value.

Fix Table 1 and 3
- NA in Table 1

Ambiguity about the relationship between "Format" and text strings???

ANALYSIS PATH/DATA THAT LED TO SPECIFICATION

Careful reading of the specification revealed that these items are misleading and/or redundant. The proposed changes take into account the removal of the Use_Init_Output Boolean in the proposed reference flow.

ANY OTHER BACKGROUND INFORMATION:
