Receiver Voltage with Dynamic Area Overshoot Limits
D_overshoot_ampl_h
D_overshoot_area_h
[Power Clamp Reference]
Passes – Does Not Exceed Overshoot Area or Amplitude
Fails – Exceeds Overshoot Area and Amplitude
[GND Clamp Reference]
D_overshoot_area_l
D_overshoot_ampl_l
Time