

Update on **BIRD226**: PSIJ Sensitivity

Approved on December 8, 2023

PSIJ = Power Supply Induced Jitter

Kinger Cai, Fern Nee Tan, Chi-te Chen, Michael Mirmak

May 2024





Presenter



Kinger Cai, *Principal Engineer* Platform Electrical Architect, CCG, Intel Corp. Kinger.Cai@intel.com

Kinger leads AI PC coherent architecture strategy in mobile platforms and drives strategic platform EDA tools & algorithms evolution in Intel. Kinger obtained Ph. D from Shanghai Jiao Tong University in 2001, and achieved MBA degree from W.P. Carey business school in ASU in 2008. Kinger has focused on signal & power integrity domains for 20+ years. Kinger holds 14 granted patents, and published 30+ papers.

Executive Summary

Summary:

 BIRD226 focuses on including all PSIJ contributions from all PI noises, of each power supply rail, and all power rails, to all involved ckt blocks, for an interface operating in a particular protocol, supporting system level PI and SI co-simulation / design.



BIRD226 for PI & SI Co-sim. Major Steps

- 1. SI simulation sets up all involved power supplies ideal at Vnom/Vmin/Vmax, (which is equivalent to "disabling" of BIRD220, and/or [ISSO PU] & [ISSO PD], and [Composite Current]).
- 2. Takes into consideration the total PI noises of each power supply rail, including (1) self-noise, (2) coupling noise and (3) power management relevant noise; while taking care of multiple power supplies to one IO interface simultaneously.
- 3. Takes into consideration the jitter impact to all relevant ckt blocks from total PI noise of each power supply rail, which will be calculated with defined/ <u>IEEE published algorithm</u> for PSIJ.
- 4. All involved power rails' jitter values to a concerned IO interface, can be super-positioned upon the eye-diagram resulting from SI simulation with ideal power supplies setup, or super-positioned upon Tx_Dj or Rx_Dj in IBIS-AMI.





brid IBIS Summit with IEEE SPI 2024

Other names and brands may be claimed as the property of others. All products, computer systems, dates and figures specified are preliminary based on current expectations, and are subject to change without notice.

PSIJ Sensitivity Derivation

- Set up VCC_m, all other powers at their own Vtyp, while sweeping f, get jitter impact
 - $VCC_m = Vtyp + A*sin(2*Pi*f)$,
 - *A*=(*Vmax-Vmin*)/2,
 - $PSIJ_VCC_m_ckt_i(f) = Jitter_{PP}(f)/(2*A)$
- VCC_m power supplies multiple CKT blocks
 JTF_i(f) = Jitter_of_S_{out}_i(f) /Jitter_of_S_{in}_i(f)
 PSIJ_Vcc_m_i = PSIJ_Vcc_m_(i-1) * JTF_i +
 PSIJ_Vcc_m_CKT_i, i ∈ 2, ... N
 PSIJ_Vcc_m_1 = PSIJ_Vcc_m_CKT_1
 PSIJ_Vcc_m = PSIJ_Vcc_m_N



Other names and brands may be claimed as the property of others. All products, computer systems, dates and figures specified are preliminary based on current expectations, and are subject to change without notice.

Function

Jitter Transfe

intel

[PSIJ Sensitivity] Tree Structure in .ibs



Tale 2- IBIS Keywords and Subparameters

Keywords or	Notes		
subparameter			
[PSIJ Sensitivity]	It is optional in a .ibs file.		
[PSIJ Sensitivity Rail]	It is optional in a .ibs file. It is required within		
	[PSIJ Sensitivity].		
[PSIJ Sensitivity Signal]	It is optional in a .ibs file. It is required within		
	[PSIJ Sensitivity Rail].		
[End PSIJ Sensitivity	It is optional in a .ibs file. It is required within		
Signal]	[PSIJ Sensitivity Signal].		
[PSIJ Voltage List]	It is optional in a .ibs file. It is required with		
	[PSIJ Sensitivity Rail].		
[End PSIJ Voltage List]	It is optional in a .ibs file. It is required with		
	[PSIJ Voltage List].		
[End PSIJ Sensitivity	It is optional in a .ibs file. It is required with		
Rail]	[PSIJ Sensitivity Rail].		
[End PSIJ Sensitivity]	It is optional in a .ibs file. It is required with		
	[PSIJ Sensitivity].		

6

[PSIJ Sensitivity] Definition in IBIS

Keyword: [PSIJ Sensitivity]

Required: No. Required when [PSIJ Sensitivity Rail] is defined for at least one power supply rail in an I/O interface operating in a particular standard or protocol.

Description: Declares operating protocol of an I/O interface and the beginning of [PSIJ Sensitivity Rail] for the power supply rails.

Usage Rules: The [PSIJ Sensitivity] / [End PSIJ Sensitivity] keyword pair is used to define a list of [PSIJ Sensitivity Rail]s by name that shall be used together for one concerned IO interface operating in a particular standard or protocol in a simulation. A simulation may contain [PSIJ Sensitivity Rail]s of all power rails listed in only one keyword pair of [PSIJ Sensitivity] and [End PSIJ Sensitivity]. The [PSIJ Sensitivity] / [End PSIJ Sensitivity] keyword pair is hierarchically scoped by the [Component] keyword.

```
Example:

[PSIJ Sensitivity] PCIe_Gen4

| ...

[End PSIJ Sensitivity]

[PSIJ Sensitivity] PCIe_Gen5

| ...

[End PSIJ Sensitivity]

| ...

[PSIJ Sensitivity] TypeC

| ...

[End PSIJ Sensitivity]
```

[PSIJ Sensitivity Rail] Definition in IBIS

Keyword: [PSIJ Sensitivity Rail]

Required: No. Required when [PSIJ Sensitivity Rail] is defined for at least one power supply rail in an I/O interface.

Description: This keyword pair declares the IO POWER supply rail and its unique reference GND, with the next level two keywords of signal_name at pin level. One signal_name is for Power, and the other signal_name for the reference GND.

Sub-Params: signal_name

Usage Rules: The keyword [PSIJ Sensitivity Rail] accepts a string argument, on the same line, which is usually listed as PSR_of_<signal_name> of a POWER supply rail. This string argument shall be no longer than 40 characters and shall not include whitespace.

The keyword pair of [PSIJ Sensitivity Rail] and [End PSIJ Sensitivity Rail] may appear multiple times, each with a unique PSR_of_<signal_name> of a POWER supply rail, within a keyword pair of [PSIJ Sensitivity] and [End PSIJ Sensitivity] for the POWER supply rails in one I/O interface operating in one standard or protocol.

• • • • • •

Example:

```
[PSIJ Sensitivity] LPDDR4
[PSIJ Sensitivity Rail] PSR of VDD1
signal name VDD1 | signal name VDD1 is an
IO power supply rail for LPDDR4 PHY.
signal name Vss
 ...
[End PSIJ Sensitivity Rail]
[PSIJ Sensitivity Rail] PSR of VDD2
signal name VDD2 | signal name VDD2 is an
IO power supply rail for LPDDR4 PHY.
signal name Vss
| ...
[End PSIJ Sensitivity Rail]
[PSIJ Sensitivity Rail] PSR of VDDQ
signal name VDDQ | signal name VDDQ is an
IO power supply rail for LPDDR4 PHY.
signal name VSS
 ...
[End PSIJ Sensitivity Rail]
[End PSIJ Sensitivity]
```

[PSIJ Sensitivity Signal] Definition in IBIS

Keyword: [PSIJ Sensitivity Signal]

Required: No. Required when [PSIJ Sensitivity Signal] is defined for at least one type of signals in an I/O interface operating in a particular standard, or protocol.

Description: This keyword pair describes the Power Supply Induced Jitter (PSIJ) sensitivity in PWL (Piece Wise Linear) table format in the frequency domain for a type of signals operating in the particular protocol of [PSIJ Sensitivity], to evaluate the jitter impact to the [PSIJ Sensitivity Signal] through all involved circuit blocks from the total power supply noise of the [PSIJ Sensitivity Rail].

Sub-Params: model_name

Usage Rules: The keyword [PSIJ Sensitivity Signal] is followed by the next level keyword model_name, on the next line, which is model name for the concerned type of signals .



Example:

[PSIJ Sensitivity] PCIe Gen4 [PSIJ Sensitivity Rail] PSR of VCC2 signal name VCC2 <mark>signal name VSS</mark> [PSIJ Sensitivity Signal] model name PCIe Gen4 TX model name defined for same IO signals in the [Pin]. | frequency (Hz) magnitude(s/V) phase (degree) 0.0 1.00E 0 1.00E-12 1.0E+03 0 1.0E+04 2.00E-12 0 4.0E+05 1.20E-09 0 1.0E+06 3.00E-09 0 1.0E+07 5.40E-09 0 2.0E+07 5.80E-09 0 1.0E+08 4.50E-09 0 1.0E+09 4.30E-09 0 [End PSIJ Sensitivity Signal] [End PSIJ Sensitivity Rail]

[PSIJ Volt	<mark>age List]</mark>		
V(name)	V(typ)	V(min)	V(max)
VCC2	0.600	0.540	0.660
VSS	0.000	0.000	0.000
[End PSIJ	Sensitivity]		



Hybrid IBIS Summit with IEEE SPI 2024

Other names and brands may be claimed as the property of others. All products, computer systems, dates and figures specified are preliminary based on current expectations, and are subject to change without notice.

9

[PSIJ Sensitivity] Facilitates Quick IP Selection

- Same IP is better:
 - from vendor2 than
 - from vendor1
- Same IP is better:
 - upon process1 than
 - upon process2
- Same IP is the best
 - from vendor2 and
 - upon process1.



BIRD226 can well handle #1/2/3

- 1. One power supplier to Multiple Buffers of the same, VCCIO to all 512bits GDDR
- 2. Multiple power suppliers to one Buffer, VCCIO & VDDQ to 1-bits GDDR
- 3. Multiple power suppliers to multiple Buffers of the same, VCCIO & VDDQ to all 512bits GDDR

Things need to be considered, might be very challenging with traditional SIPI co-sim algorithm:

- 1) If a V(t) waveform is directly applied to the SI simulation, there is synchronization concern,
- 2) Whole PDN need to be included in the sim deck, to reflect the real-time voltage waveform
- 3) Stimulating bits pattern is tricky for each bit/DQ of all 512 bits, might need to apply PDF

BIRD226 can well handle #4

- 1. One power supplier to Multiple Buffers of the same, VCCIO to all 512bits GDDR
- 2. Multiple power suppliers to one Buffer, VCCIO & VDDQ to 1-bits GDDR
- 3. Multiple power suppliers to multiple Buffers of the same, VCCIO & VDDQ to all 512bits GDDR
- 4. One/multiple power supplier(s) to multiple interfaces, VCCIO to the interfaces of GDDR PCIe4/5, DP/HDMI/USB3, etc.

1

2

3)

SIPI co-sim algorithm:

Other names and brands may be claimed as the property of others. All products, computer systems, dates and figures specified are preliminary based on current expectations, and are subject to change without notice.

Takeaway

- BIRD226 focused on system level PI & SI co-simulation/design:
 - 1) SI simulation sets up all involved power supplies ideal at Vnom/Vmin/Vmax, (which is equivalent to disabling of BIRD220, or [ISSO PU] & [ISSO PD], and [Composite Current].)
 - 2) PI simulation for each involved power rail, includes the contribution from all involved interfaces, and the power management events (multiple stages of sleep/wake-up)
 - 3) The algorithm of PI contributing jitter from each involved power rails is specified in <u>https://ieeexplore.ieee.org/stamp/stamp.jsp?arnumber=4387157</u>
 - 4) All involved power rails' jitter values can be super-positioned upon the eye-diagram from SI simulation as specified in item#1, or upon Tx_Dj or Rx_Dj in IBIS-AMI.
- BIRD226 can handle all listed scenarios:
 - One/multiple power suppliers, to one/multiple Buffer(/bit/lane/interface)s.

Legal Disclaimer

You may not use or facilitate the use of this document in connection with any infringement or other legal analysis concerning Intel products described herein. You agree to grant Intel a non-exclusive, royalty-free license to any patent claim thereafter drafted which includes subject matter disclosed herein.

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

Intel technologies' features and benefits depend on system configuration and may require enabled hardware, software or service activation. Learn more at Intel.com, or from the OEM or retailer.

No computer system can be absolutely secure. Intel does not assume any liability for lost or stolen data or systems or any damages resulting from such losses.

The products described may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

Intel technologies' features and benefits depend on system configuration and may require enabled hardware, software or service activation. Learn more at intel.com, or from the OEM or retailer.

All information provided here is subject to change without notice. Contact your Intel representative to obtain the latest Intel product specifications and roadmaps.

Copies of documents which have an order number and are referenced in this document may be obtained by calling 1-800-548-4725 or visit www.intel.com/design/literature.htm.

Intel, and the Intel logo are trademarks of Intel Corporation in the U.S. and/or other countries.

*Other names and brands may be claimed as the property of others.

© 2022 Intel Corporation. All rights reserved.

THANK YOU!

Kinger.cai@intel.com