

Sparse Matrix Mapping Draft 9

1/20/2010

[Number of Sparse Labels]

Rules for Version 1.0-2.0 files:

[Number of Sparse Labels] is not permitted in Version 1.0-2.0 files.

Rules for Version 2.1 Files:

[Number of Sparse Labels] is an optional keyword describing how many data pairs will appear for each frequency in [Network Data], and how many integer-labels will appear under the [Sparse Matrix Mapping] keyword.

Note that, if [Number of Sparse Labels] is present, the number of entries under [Network Data] does NOT need to match the size of a matrix given by [Number of Ports] x [Number of Ports]. Instead, the number of data pairs under the [Network Data] keyword must match the number of integer-labels under the [Sparse Matrix Mapping] keyword.

[Number of Sparse Labels] is required if [Sparse Matrix Mapping] is present. Otherwise, it is prohibited.

[Number of Sparse Labels] accepts a single integer argument with value greater than zero. The value must match the number of integer-labels used under [Sparse Matrix Mapping]. The [Number of Sparse Labels] keyword is followed by a single positive integer argument, separated from the keyword by whitespace.

[Number of Sparse Labels] shall appear after the [Number of Ports] keyword and before any network data.

[Sparse Matrix Mapping]

Rules for Version 1.0-2.0 files:

[Sparse Matrix Mapping] is not permitted in Version 1.0-2.0 files.

Rules for Version 2.1 files:

[Sparse Matrix Mapping] is an optional keyword describing how the data under [Network Data] maps into the n-port matrix ($n \times n$), where n is given by [Number of Ports].

[Sparse Matrix Mapping] shall appear after the [Number of Ports] keyword and before any network data. The [Network Data] keyword data given later in the file changes in

meaning from expressing data for an $n \times n$ matrix to expressing the data points remapped into the $n \times n$ matrix by the contents of the [Sparse Matrix Mapping] keyword.

[Sparse Matrix Mapping] contains two kinds of arguments: integer-labels and index-pairs. Integer-labels are integer numbers greater than or equal to 1 and less than or equal to n^2 , followed by the colon character without any whitespace.

[\[Sparse Matrix Mapping\] and its arguments may span multiple lines.](#)

An index-pair is a pair of positive integers between 1 and n , separated without any space by the comma character and enclosed, without whitespace, by parentheses. An index-pair specifies the row and column index in the n -port matrix into which the [Network Data] is mapped by [Sparse Matrix Mapping]. All index-pairs after an integer-label and before the next integer-label or the end of [Sparse Matrix Mapping] refer to the data pair under [Network Data] corresponding to the first integer-label and therefore force the corresponding entries in the $n \times n$ matrix to be identical.

Integer-labels are required if [Sparse Matrix Mapping] is present, must be numerically increasing and the sequence must begin with 1.

Integer-labels may not be re-used. Index-pairs may not be duplicated either within an integer-label group or between two or more integer-label groups.

The last integer-label shall be the same as the [Number of Sparse Labels].

White space is not permitted between the integer-label's integer value and the colon character.

In each index-pair, the row index is always the first integer and the column index is always the second. Zero values are not permitted within an index-pair. The value for any row or column index in an index-pair must be no larger than the [Number of Ports] argument.

For example, if the very first index-pair under [Sparse Matrix Mapping] is (1,5) and the first data pair under [Network Data] is the real/imaginary pair 7 -0.8, then the values 7 -0.8 are assumed to occupy row 1, column 5 of the n -port matrix described by [Number of Ports].

The row and column indices in an index-pair are separated by a comma, are preceded by an open parenthesis and followed by a close parenthesis.

White space is not permitted after the open parenthesis and before the closed parenthesis of an index-pair. White space is required between index-pairs.

Data in the n-port matrix that is not indicated by an index-pair under [Sparse Matrix Mapping] is assumed to be zero-valued, corresponding to a value with zero real and zero imaginary part, regardless of the data format applied in the [Network Data] section..

[Sparse Matrix Mapping] assumes that the matrix mapping between its entries and those of [Network Data] apply across all frequency points given under [Network Data].

Multiple integer-labels may appear on the same line. Integer-labels and associated index-pairs may be separated by a line-termination sequence. Empty integer-labels (integer-labels followed by other integer-labels without an intervening index-pair) are not permitted.

[Sparse Matrix Mapping] must contain at least one integer-label. The number of integer-labels must agree with the argument used for [Number of Sparse Labels].

Lists of index-pairs may span multiple lines.

The maximum number of index-pairs under [Sparse Matrix Mapping] is given by the square of the argument to [Number of Ports].

Note that [Mixed-Mode Order], [Matrix Format], [Reference Impedance] and [Number of Ports] rules do not change in the presence of [Number of Sparse Labels]. [Mixed-Mode Order], [Matrix Format] and [Reference Impedance] describe the matrix populated by the contents of [Sparse Matrix Mapping] and [Network Data]. [Number of Ports] describes the matrix into which [Sparse Matrix Mapping] arguments map the data under [Network Data].

When [Matrix Format] is “Upper” then the row index of any index-pair must be less than or equal to column index of that pair. Similarly, when [Matrix Format] is “Lower” then the row index of any index-pair must be greater than or equal to the column index of that pair. For either “Upper” or “Lower” [Matrix Format], the number of index-pairs shall not exceed $(n^2 + n)/2$, where n is the number of ports given by [Number of Ports].

Example xx (Version 2.0):

```
[Version] 2.0
# GHz S MA R 50
[Number of Ports] 4
[Number of Frequencies] 1
[Reference] 50 75 0.01 0.01
[Matrix Format] Full
[Number of Sparse Labels]
3
[Sparse Matrix Mapping]
1: (1,1) (2,2) (1,3) (3,3) (4,4) 2: (3,1) 3: (4,1) (2,1) (1,4) (4,3)
```

[Network Data]

5.00000 0.60 161.24 0.40 -42.20 0.42 -66.58

[End]

This describes the 4x4 matrix shown below:

0.60 161.24	0 0	0.60 161.24	0.42 -66.58
0.42 -66.58	0.60 161.24	0 0	0 0
0.40 -42.20	0 0	0.60 161.24	0 0
0.42 -66.58	0 0	0.42 -66.58	0.60 161.24

The representation below is also permitted:

[Sparse Matrix Mapping]

1: (1,1) (2,2) (1,3) (3,3) (4,4)

2: (3,1)

3: (4,1) (2,1) (4,3) (1,4)

[Network Data]

...

Example xx (Version 2.0):

[Version] 2.0

GHz S MA R 50

[Number of Ports] 4

[Number of Frequencies] 1

[Reference] 50 75 0.01 0.01

[Matrix Format] Lower

[Number of Sparse Labels]

4

[Sparse Matrix Mapping]

1: (1,1) (2,2) (3,3) (4,4) 2: (3,1) (4,2) 3: (2,1) (3,2) (4,3) 4: (4,1)

[Network Data]

5.00000 0.60 161.24 0.40 -42.20 0.42 -66.58 0.38 -20.03

[End]

This describes the 4x4 lower-half matrix shown below:

0.60 161.24			
0.42 -66.58	0.60 161.24		
0.40 -42.20	0.42 -66.58	0.60 161.24	
0.38 -20.03	0.40 -42.20	0.42 -66.58	0.60 161.24

The representation below is also permitted

[Sparse Matrix Mapping]

1: (1,1) (2,2) (3,3) (4,4)

2: (3,1) (4,2)

3: (2,1) (3,2) (4,3)

4: (4,1)

[Network Data]

...