

Interconnect Modeling Using IBIS-ISS and Touchstone



Michael Mirmak

Intel Corporation

michael.mirmak@intel.com

EDICON IBIS Summit
Boston, Massachusetts
September 13, 2017

Updated from May 10, 2017 SPI2017 IBIS Summit presentation
Presented by Mike LaBonte, SiSoft

IBIS Summit at EDICON 2017

Agenda

- ❑ History
- ❑ The Need for Improved Interconnect Support
- ❑ Principles of the Interconnect Proposal
 - Structure
 - Terminals, Models and Sets
 - New Keywords
- ❑ An Example Explained
- ❑ Summary

History

- ❑ Interconnect Task Group resumed meeting in early 2014
 - Received draft BIRD from Walter Katz (SiSoft) to support IBIS-ISS packages within IBIS

- ❑ BIRD189.4 available for review
 - <http://www.ibis.org/birds/birds189.4.docx>
 - ~40 pages with examples
 - Comments welcome

- ❑ Intended for IBIS Version 7.0

- ❑ Brief overview with some key points is given here

Why Update Interconnect Modeling?

- ❑ Improve package models with IBIS-ISS (a Synopsys HSPICE* subset) and Touchstone support

- ❑ Package modeling in IBIS unchanged since 2000
 - [Pin], [Package], [Package Model]
 - [Alternate Package Models] selector added
 - Limited support of loss, crosstalk and/or partitioning

- ❑ EBD (Electrical Board Description) for boards: no coupling and limited package model application


- ❑ IBIS, IBIS-ISS, Touchstone 2.0 and ICM are separate specifications
 - Limited interaction between them for package modeling
 - ICM (Interconnect Model) never adopted by industry

Features of the Interconnect Proposal

- Supports...
 - IBIS-ISS and Touchstone models (common in industry)
 - Both I/O and supply (POWER and GND) connections
 - (New) optional Die pad interface between Pins and Buffers
 - I/O pin_names as terminal qualifiers
 - *May have optional Aggressor_Only designation*
 - POWER and GND terminal qualifiers by pin_name, pad_name, signal_name or [Pin Mapping] bus_label for rail connections with direct or combined terminals
 - Plus many other features not covered here...


A few objectives for the
Interconnect Modeling proposal

Structure of the Interconnect Proposal




Introduces optional Die Pad interface for terminals separate from Buffer and Pin terminals

Relates to Physical Structures



One-to-one path connection; Die Pad interface optional;
Aggressor_Only designation optional

Terminals at Buffer, Die Pad and Pin Interfaces




Original IBIS (4.0 and earlier)

- Pins are explicit
- Buffer terminals implicit in [Model]
- Die pad terminals same as buffer terminals
- Packages defined connections between pins and buffers

Current Proposal

- Die pad terminals are now explicit
- Buffer terminals are now explicit
- [Pin]s are.... still pins
- Separate interconnect definitions can be created between ...
 - Pin-to-Die pad terminals,
 - Die pad-to-Buffer terminals,
 - Pin-to-Buffer terminals (still) supported

Physical Rails (Can be Merged)



New Keywords and Subparameters (Limited Discussion Here)

- [Bus Labels] | bus_label
- [Die Supply Pads] | pad_name, optional bus_label
- [Interconnect Model]/[End Interconnect Model]
 - Param | parameter passing
 - File_IBIS-ISS | names IBIS-ISS file
 - File_TS | names Tstone file
 - Number_of_terminals=<value> | number of terminals
 - <terminal lines> | described later
- [Interconnect Model Set]/[End Interconnect Model Set]
- [Interconnect Model Set Selector]/[End Interconnect Model Set Selector]

[Interconnect Models]

□ [Interconnect Models]

- Connections between terminals with IBIS-ISS or Touchstone files
- Terminal connection points at Buffer, Die pad, or Pin interfaces
- Identifies rail or I/O terminals
- Allows pin_name, signal_name, pad_name, or bus_label terminal qualifiers for rails (and pin_name for I/O terminals)
- Identifies whether a coupled signal is only an aggressor or also “experiences” coupling from other sources

How package and on-die electrical information
is generated and delivered today

[Interconnect Model Set]s

- [Interconnect Model Set]s
 - Groups Interconnect Models
 - Can be used (and is recommended) to establish a complete path
 - Can be grouped with selection controls for individual simulations, similar to [Model] and [Model Selector]

- Some Example Groupings and Applications
 - Separate sets, one per interface (e.g., memory, network)
 - Separate sets for coupled vs. single-line simulations
 - Different sets for different power delivery network complexities
 - *POWER connected at single pin, single buffer terminal*
 - *POWER connected through multiple pins, rails to individual buffer terminals*

<Terminal lines> Syntax

- All column entries on one line:

<Terminal_number> <Terminal_type>
 <Terminal_type_qualifier> <Qualifier_entry>
 [Aggressor_Only]

- <Terminal_number> is IBIS-ISS node position or Touchstone port number
- Allowable <Terminal_type> names and associations next


Allowable <Terminal_type> Associations

<Terminal_number> <Terminal_type> <Terminal_type_qualifier> <Qualifier_entry> [Aggressor_Only]

Terminal_type	Terminal_type_qualifier				Aggressor_Only
	pin_name	signal_name	bus_label	pad_name	
Pin_I/O	X				A
Pad_I/O	X				A
Buffer_I/O	X				A
Pin_Rail	Y	Y	Y		
Pad_Rail		Y	Y	Z	
Buffer_Rail		Y	Y		
Pullup_ref	X				
Pulldown_ref	X				
Power_clamp_ref	X				
Gnd_clamp_ref	X				
Ext_ref	X				

<Qualifier_entry>: "X" I/O pin_name; "Y," or "Z": POWER or GND name. Optional "A": "Aggressor_Only"

Example Showing Connections



[Die Supply Pads] for pad_names Shown in Example

The [Die Supply Pads] keyword establishes pad_name <Qualifier_entries> for rails, and associates them with signal_name (and optionally with bus_label entries)


```
[Die Supply Pads] signal_name bus_label  
| pad_name  
VDDQ                VDD  
VSSQ                VSS
```

[Interconnect Model] for Buffer-to-Die Pad Side

```

[Interconnect Model Set] Full_ISS_PDN
|
[Interconnect Model] Partial_ISS_buf_pad
|
File_IBIS-ISS      buf_pad.iss  buf_pad_2_typ
Number_of_terminals = 10
|
1  Pad_I/O          pin_name    A1 | DQ1 (DQ signal)
2  Pad_I/O          pin_name    A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with pad_names and pin_names
3  Pullup_ref       pin_name    A1 | VDD (POWER connection)
4  Pulldown_ref     pin_name    A1 | VSS (GND connection)
5  Buffer_I/O       pin_name    A1 | DQ1 (DQ signal)
6  Pullup_ref       pin_name    A2 | VDD (POWER connection)
7  Pulldown_ref     pin_name    A2 | VSS (GND connection)
8  Buffer_I/O       pin_name    A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with signal_names
9  Pad_Rail         pad_name    VDDQ | VDD POWER
10 Pad_Rail         pad_name    VSSQ | VSS GND
|
[End Interconnect Model]

```




[Interconnect Model] for Buffer-to-Die Pad Side (Expanded)

```
[Interconnect Model Set] Full_ISS_PDN
|
[Interconnect Model] Partial_ISS_buf_pad
|
File_IBIS-ISS          buf_pad.iss  buf_pad_2_typ
Number_of_terminals = 10
|
1  Pad_I/O             pin_name    A1 | DQ1 (DQ signal)
2  Pad_I/O             pin_name    A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with pad_names and pin_names
3  Pullup_ref          pin_name    A1 | VDD (POWER connection)
4  Pulldown_ref        pin_name    A1 | VSS (GND connection)
5  Buffer_I/O          pin_name    A1 | DQ1 (DQ signal)
6  Pullup_ref          pin_name    A2 | VDD (POWER connection)
7  Pulldown_ref        pin_name    A2 | VSS (GND connection)
8  Buffer_I/O          pin_name    A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with signal_names
9  Pad_Rail            pad_name    VDDQ | VDD  POWER
10 Pad_Rail            pad_name    VSSQ | VSS  GND
|
[End Interconnect Model]
```

[Interconnect Model]
File and subcircuit

<Terminal lines> for
connecting the
subcircuit nodes (by
position) to the
interconnect
structure

[Interconnect Model] for Die Pad-to-Pin Side



C1 VDD POWER
A1 DQ1 DATA_MODEL
C2 VSS GND
A2 DQ2 DATA_MODEL

```
[Interconnect Model] Partial_ISS_pad_pin_2
|
File_IBIS-ISS          pad_pin.iss  pad_pin_2_typ
Number_of_terminals = 8
|
1  Pin_I/O      pin_name      A1 | DQ1 (DQ signal)
2  Pin_I/O      pin_name      A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with signal_names
3  Pin_Rail     signal_name    VDD | VDD (POWER connection)
4  Pin_Rail     signal_name    VSS | VSS (GND connection)
5  Pad_I/O      pin_name      A1 | DQ1 (DQ signal)
6  Pad_I/O      pin_name      A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with pad_names
7  Pad_Rail     pad_name      VDDQ | pad_name with VDD
8  Pad_Rail     pad_name      VSSQ | pad_name with VSS
|
[End Interconnect Model]
|
[End Interconnect Model Set]
```

[Interconnect Model] for Die Pad-to-Pin Side (Expanded)

[Interconnect Model]

File and subcircuit

<Terminal lines> for connecting the subcircuit nodes (by position) to the interconnect structure


```
[Interconnect Model] Partial_ISS_pad_pin_2
|
File_IBIS-ISS          pad_pin.iss  pad_pin_2_typ
Number_of_terminals = 8
|
1  Pin_I/O      pin_name      A1 | DQ1 (DQ signal)
2  Pin_I/O      pin_name      A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with signal_names
3  Pin_Rail     signal_name    VDD | VDD (POWER connection)
4  Pin_Rail     signal_name    VSS | VSS (GND connection)
5  Pad_I/O      pin_name       A1 | DQ1 (DQ signal)
6  Pad_I/O      pin_name       A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with pad_names
7  Pad_Rail     pad_name       VDDQ | pad_name with VDD
8  Pad_Rail     pad_name       VSSQ | pad_name with VSS
|
[End Interconnect Model]
|
[End Interconnect Model Set]
```

Complete [Interconnect Model Set] With Both [Interconnect Models]

[Interconnect Model Set]



[Interconnect Models]



```
[Interconnect Model Set] Full_ISS_PDN
|
[Interconnect Model] Partial_ISS_buf_pad
|
File_IBIS-ISS      buf_pad.iss  buf_pad_2_typ
Number_of_terminals = 10
|
1  Pad_I/O      pin_name      A1 | DQ1 (DQ signal)
2  Pad_I/O      pin_name      A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with pad_names and pin_names
3  Pullup_ref   pin_name      A1 | VDD (POWER connection)
4  Pulldown_ref pin_name      A1 | VSS (GND connection)
5  Buffer_I/O   pin_name      A1 | DQ1 (DQ signal)
6  Pullup_ref   pin_name      A2 | VDD (POWER connection)
7  Pulldown_ref pin_name      A2 | VSS (GND connection)
8  Buffer_I/O   pin_name      A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with signal_names
9  Pad_Rail     pad_name      VDDQ | VDD POWER
10 Pad_Rail     pad_name      VSSQ | VSS GND
|
[End Interconnect Model]
```

```
[Interconnect Model] Partial_ISS_pad_pin_2
|
File_IBIS-ISS      pad_pin.iss  pad_pin_2_typ
Number_of_terminals = 8
|
1  Pin_I/O      pin_name      A1 | DQ1 (DQ signal)
2  Pin_I/O      pin_name      A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with signal_names
3  Pin_Rail     signal_name  VDD | VDD (POWER connection)
4  Pin_Rail     signal_name  VSS | VSS (GND connection)
5  Pad_I/O      pin_name      A1 | DQ1 (DQ signal)
6  Pad_I/O      pin_name      A2 | DQ2 (DQ signal)
|
| POWER and GND terminals with pad_names
7  Pad_Rail     pad_name      VDDQ | VDD is signal name
8  Pad_Rail     pad_name      VSSQ | VSS is signal name
|
[End Interconnect Model]
|
[End Interconnect Model Set]
```



[End Interconnect Model Set]

Summary

- ❑ BIRD189.4 improves IBIS package modeling
 - More revisions coming through the IBIS Interconnect Task Group
- ❑ Links IBIS, IBIS-ISS and Touchstone for package models
 - Adds flexible support for package loss, crosstalk and partitioning
- ❑ Formalizes and separates Die pads and Buffers
- ❑ Other extensions (not covered here) included

New advanced Interconnect format for IBIS Version 7.0!